

Assembly Instructions for 5'x10' Goals FOR U7/U8G (Agora SA-G51005)

Goal bag contains the following:

1. Two side posts **A** (blue/green)
2. Two corner posts **B**: 1 top (blue), 1 bottom (brown)
3. Two corner posts with snap buttons **C**: 1 top (blue), 1 bottom (brown)
4. Two bottom posts **D** (green)
5. 1 net
6. 1 red back with 1 Mallet and 4 stakes
7. 2 corner flags (maybe not)

Goal Assembly

Carry the bag to the goalie box

- Assemble the goal frame using the push button
 - Blue tape is the top,
 - Sky blue/green on sides
 - Brown on ground
- Unfold net and find the two top corner tags.
- Drape the net over the goal and attach the top corner tags to the top corners of the goal using the net clips.
- Fasten the net to the rest of the top and side bars.
- Flip the goal down with the brown tape bottom up and repeat the attachment process. You can tighten the goal to your preference.
- Position the goal behind the line.
- Stake the goal to the ground to prevent it from flipping over and hitting the kids - two stakes on both sides and two in the back.

